

Replacement Parts

ITEM	PART #	DESCRIPTION
1	CE057	INDICATOR LIGHT
2	CE266	IGNITION MODULE- MODELS - UA/UX
	CE201	IGNITION MODULE- MODELS - UXR
3	CG142	HONEYWELL VALVE TRAIN REPLACEMENT KIT - NAT.
	CG143	HONEYWELL VALVE TRAIN REPLACEMENT KIT - LPG.
4	CE058	TRANSFORMER
5	CE133	BLOWER FOR U & T MODELS - 40,000 TO 175,000 BTU
	CE013	BLOWER MOTOR - 205,000 TO 220,000 BTU
6	CH007	BLOWER GASKET
7	CE003	FLAME SENSOR ELECTRODE
8	CE002	SPARK ELECTRODE
9	CE006	IGNITION WIRE

ITEM	PART #	DESCRIPTION
10	UG001P	BURNER CUP
	UG007	BURNER CUP ASSEMBLY (C/W ELECTRODES)
11	CH011	SIGHT GLASS ASSEMBLY
12	CE020	AIR SWITCH - MODELS - 40,000 & 60,000 BTU
	CE021	AIR SWITCH - MODELS - 80,000 & 100,000 BTU
	CE024	AIR SWITCH - MODELS - 125,000 & 150,000 & 205,000 BTU
	CE023	AIR SWITCH - MODELS - 220,000 BTU
	CE022	AIR SWITCH - MODELS - 175,000 BTU
13	CE010	POWER CORD
14	CH001	BURNER GASKET
15	VS022	AIR INLET KIT

